SERVISE AND MAINTENANCE MANUAL OF MOBILE ASPIRATOR CUMA D-MO

Mobile aspirator consists of:

- a) Filter line CUMA D-MO
- b) Radial moderated pressure transport aspirator

Filter with the aspirator forms a self-contend unit; to its functionality we provide 12 months promissory warranty

The warranty does not apply to a filter medium used up by filtering an unsuitable product or spoiled.

Service and Maintenance manual:

To prevent the equipment from an incorrect usage read thoroughly *the service instructions and enclosed brochure* before using it.

CUMA D-MO Filter Maintenance:

- 1) CUMA D-MO Filters are constructed as single-purpose mobile separators, which are necessary to be turned off and set into a sleep mode to regenerate the filter medium. After that gently tip on the filter's bag several times, on few different places around its perimeter to trash out the dust from the inner side of the bag.
- 2) It is necessary to keep the direction of rotation vane wheel, which is marked with an arrow at visible place.
- 3) When changing the collecting bag make sure that its tightened and correctly fixed.
- 4) The average used up filter bag is necessary to change once in 1 to 3 years.
- 5) When sucking sticky or cohesive material it may cause that the material will stick on the fan's vane wheel and causes the wheel imbalance and following vibrations.

 In that case you have to demount the lid of the suction-fan and clean the vane wheel.

Service:

In case of need please contact our service department:

tel.: 00420-545220506
 fax: 00420-545220507
 e-mail: servis@cipres.cz